

## **OVER SPEED CAR FOR DELTA B+ DRIVE**

SET PARAMETER 01-00 (HIGH SPEED MAX. FREQ. LIMIT) TO 90

SET PARAMETER 05-00 (HIGH SPEED SETTING) TO 90

WHEN A CALL IS PLACED THE CAR WILL TRY TO RUN AT CONTRACT SPEED PLUS 50%.